

TRIUMPH ROCKET 3

Quick Release Sissy Bar Brackets and Mounting kit.

Classic, Standard and Roadster – All years to 2015



Standard Covers with Standard Bolts.



Replace Standard Bolts with the kit provided.
The M10 Cap Screw Bolt kit replaces the front bolt
The M8 Cap Screw Bolt kit replaces the rear bolt
This is how it looks when the rack is NOT fitted.



Bolts with mounting kits fitted.



Stainless Steel Brackets fitted to Triumph Rack and Sissy Bar.



Close up of assembled parts.
Assemble these parts "FINGER TIGHT" for now.
Once the mounting kit is fitted and the bolts backed out by about one turn.



Place the front slot in the mounting kit



Lower the rear slot into the mounting kit



Make sure ALL slots are all the way home and "Tighten" the Mounting Bolts up.
DON'T FORGET TO TIGHTEN THE BOLTS ON THE RACK AND BACKREST....



To remove – Simply loosen the mounting bolts half to one turn – lift the rear of the rack out and the front will follow – then TIGHTEN the bolts again so they don't fall out.
EASY AS THAT.....

THE EXTRA SLOT

The Extra slot is for EZ Brackets so you can install your saddle bags quick and easy.
I don't have a set of these so I can't show you.

This Pic was "Borrowed" from the internet (www.easybrackets.com)

